

Danver



Assembly Guide: Cosmopolitan Kitchen

TABLE OF CONTENTS

IMPORTANT: READ FIRST	3
Stainless Steel Cleaning	3
Unboxing Hardware Required Tools	4
Assembly: Single Kitchen Section	5
Assembly: Attaching Kitchen Sections	11
Assembly: Attaching Shelf Accessory	18
Assembly: Attaching Ton Mount Accessory	26



IMPORTANT: READ FIRST

- DO NOT climb on unit.
- DO NOT step or sit on shelves or drawers.
- Read and follow each step carefully. It is very important that each step is performed in the correct order.

Stainless Steel Cleaning

The following are some important tips on cleaning your stainless steel:

- There are a number of reliable stainless steel cleaners on the market
- Use only alkaline, alkaline-chlorinated or non-chloride cleaners
- · Avoid hydrochloric acid (muriatic acid) on your stainless steel
- · Always use a non-abrasive cleaning tool such as a soft cloth or plastic scouring pad
- Avoid steel pads, wire brushes and scrapers
- Always clean in the direction of the polishing marks by locating the lines or grain and scrub in a motion parallel to them
- If you do end up using a chlorinated cleaner, be sure to rinse thoroughly and dry it, immediately
- Air dry your equipment

Resources

For additional resources, such as installation videos, PDF instructions or cleaning guides, visit: danver.com/resources

Unboxing

Unboxing Instructions

- Ensure a clear and safe space for assembly.
- Remove Ends, Transitions, Rails and Shelf from box.
- · Locate and remove the hardware kits.
- Make sure adequate hardware is present for number of sections purchased


Hardware

DESCRIPTION	QTY.
T-Bolts	4 per Section
M8 Flange Nuts	4 per Section
1/4-20 Bolts	4 per Shelf Accessory

Required Tools


- Allen Wrench (provided)
- Power Screw Driver with #2 Phillips Head Bit
- #2 Phillips head manual screw driver
- Adjustable Wrench
- Level


ASSEMBLY: Single Kitchen Section







1. Slide Connectors on Rail into Channels on Legs.














3. Slide Connectors on Rail into Channels on Legs.





















4. Align Rail Flush with Top of Leg and Tighten Connectors (2x).












1. Remove Screws (4x) from Required Slats.




2. Remove Original Slats from Shelf.



3. Place Attachment Slats on Shelf




4. Fasten Attachment Slats to Shelf with Screws (4x).





5. Remove Drawer(s) from Storage Box.

6. Remove Magnetic Back Panel from Storage Box.




7. Place Storage Box on Shelf, Align Slots on Bottom of Storage Box with Holes on Attachment Slats.






9. Reattach Magnetic Back Panel to Storage Box.




10. Reattach Drawers to Storage Box.

ASSEMBLY: Attaching Top Mount Accessory




1. Remove Drawer from Storage Box.


2. Remove #10 Screws (4x) from back, remove back panel.



3. Place Top-Mounted Accessory between Upper Rails.



4. Reattach Back Panel using #10 Screws (4x).



5. Reattach Drawer to Storage Box.

